

SCHRADE **NAVITOOTM**




OWNERS MANUAL
MODEL # ST175

Introduction

Congratulations on owning our Schrade Navitool. This innovative multi-tool provides a combination of features never previously found on any tool. With stainless steel implements, precision compass, and common sense survival features, the Schrade Navitool is perfect for hunting, hiking, backpacking, camping, and more!

Features



Safe Use

Each implement is designed for specific tasks. It is recommended that each implement only be used for its intended function. Only one implement should be opened and used at any one time. Your Schrade Navitool features an exclusive locking system that provides safe, dependable operation. All implements in your Navitool (except corkscrew) lock when opened. Please read separate locking instructions before use or see diagram below.

Improper use can cause serious injury. Schrade Cutlery cannot accept liability for injuries caused by improper use or care.



1. Locked Position

2. To Unlock: Press down firmly as indicated in the illustration.



3. Then slowly rotate unlocked blade back toward housing, being careful to remove fingers and hand from path of closing blade (see illustration).

Compass Use

The compass in the Navitool is precision engineered for precise and dependable readings.

To help ensure accurate readings, simply twist compass to detach from base unit and extend tether cord to its maximum length.

Features

- Liquid filled
- Declination ring
- Lexan lens
- Luminous dial



LED Light

Your Navitool comes equipped with a super bright, high intensity, red LED light. Simply push and hold ribbed button to activate. This light is powered by a 3-volt battery (see parts replacement for more information).

Battery Replacement

A 3-volt lithium battery (model # CR2032 or comparable) powers the push-button LED light.

To replace battery:

- Twist & remove Compass module from implement pod.
- Locate U-shaped handle near bottom of signal mirror.
- Using fingernail, grasp handle and slide battery tray out.
- Remove old battery.
- Insert new battery, positive side up.
- Slide tray forward until it firmly clicks in place.
- Test light.

Lighter/Storage Compartment

One of the greatest survival dangers in the outdoors is exposure. Your Navitool comes with a convenient compartment that holds a standard disposable lighter (not included), perfect for creating a warm and useful campfire. Remember to always treat fire in the outdoors with care and caution and always extinguish your fire. Other small items may also be stored in this compartment.



Lighter/Storage Compartment

(Lighter not included)

Proper Care

The Schrade Navitool is manufactured using stainless steel implements. The large cutting blades and several of the implements are extremely sharp and should be used with respect and care. The other implements are full-sized tools designed for real challenges and must be maintained the same way any other quality tool would be.

Important!

The stainless steel used in the Schrade Navitool contains carbon. Carbon is the alloying ingredient in steel that allows the steel to be hardened and tempered to produce long-lasting cutting edges and tools that are tough and will stand up to their intended uses. Carbon in stainless steel can cause staining and corrosion under certain conditions. Therefore, always keep the Schrade Navitool cleaned, dried, and oiled periodically, especially after use in a wet environment. After cleaning, oil pivot pins and joints to ensure smooth operation.

Never

- Use the cutting blades as prybars, screwdrivers, punches or chisels.
- Hammer on the blades, implements or handles.
- Throw the tool.
- Sharpen the blades or implements on a power-driven grinding wheel.

- Expose the Schrade Navitool to extreme heat or fire.
- Clean the tool in corrosive substances. Any misuse or abuse voids your Schrade warranty.

Tether Cord

A durable tether cord that connects the compass module to the implement pod is provided for your convenience. When using the module it is important to “stretch out” the cord to its maximum length, away from the implement pod, to ensure accurate readings.

Your Navitool comes to you with cord attached. If you choose to remove cord, follow these instructions:

Removing Cord from Implement Pod

- Loosen tether loop that is threaded around bar located at bottom left corner of product.
- After loosening, extend loop approximately 3”.
- Guide compass module through 3” loop, then simply slide out cord from behind metal bar.

Removing Cord from Module

- Remove whistle from tether by sliding off open end.
- Loosen thin cord that is threaded through u-shaped metal piece on side of Module.
- Thread tether cord through loosened loop. To reattach cord simply reverse the above instructions.

Upgrade Your Navitool!

For those interested in a "higher tech" Navitool with additional features, Schrade has the answer. The IQ180CM computer module, with altimeter (up to 29,500 feet), barometer, thermometer, digital compass, clock, and stopwatch setting, represents today's finest mobile electronic gear. The computer module also calculates temperature changes, rate of ascent/descent and more! Designed by Silicon Valley's finest, the IQ180CM computer module is easily interchangeable with the Navitool standard compass. For those who demand extreme performance of themselves and their gear, the IQ180CM is the perfect upgrade. See page 11 for ordering information.



10

Ordering Schrade Navitool Parts and Accessories

To order, please call **1-800-2-SCHRADER**. Have part # and credit card (MasterCard or Visa) ready.

Parts/Accessories List:	Part #	Cost \$
• Upgraded computer module (see page 10 for details)	<u>IQ180CM</u>	<u>199.00</u>
• 2 Pack 3-Volt Batteries (for LED light)	<u>CR2032</u>	<u>6.00</u>
• Tether Cord	<u>TC1</u>	<u>2.00</u>
• Survival Whistle	<u>SRW1</u>	<u>3.00</u>

The operator **will** advise approximate shipping time and shipping & handling charge.

11

LIMITED LIFETIME WARRANTY

WHAT IS COVERED: All parts proven to be defective in materials or workmanship after factory inspection, except for light and battery which are warranted for one year only.

WHAT WE WILL DO: Replace at no charge. We reserve the right to substitute a product of equal usefulness and value.

WHAT IS NOT COVERED: Misuse, abuse, improper care or rust. Sheaths are not warranted. See use and care instructions.

WHAT PURCHASER MUST DO: Return the Navitool prepaid and insured to: Imperial Schrade Corp., 7 Schrade Court, Ellenville, N.Y. 12428-0981 Attn.: Consumer Service/Repair Dept. Please include your name and street address. Your Navitool will be returned to you prepaid. In no event shall Schrade Cutlery be liable for general, incidental or consequential damages including, without limitation, injury or damage to persons or property, arising out of any defect in this product, or arising out of any breach of the warranty made herein. Some states do not allow limitations on how long an implied warranty will last or the exclusion or limitation of incidental or consequential damage, so the above limitations or exclusions may not apply to you since this warranty gives you specific legal rights and you may also have other rights which vary from State to State.